



The Operating Principles of Rack-and-Pinion-Type HPS

① The steering wheel is turned. ()

② High-pressure oil from the hydraulic pump driven by the engine is pumped into the steering gear in the direction in which the steering wheel is turned. ()

③ This pressure pushes and pulls the tie rods connecting to the tires and changes the direction of the tires. ()

